

# **Technical data sheet**

# FM..F-SZ

Flow sensor

Calibrated ultrasonic flow sensor, temperature and glycol compensated. With DC 0.5...10 V output signal. This sensor can be used in closed cold and warm water systems and is robust against dirt and magnetite. There is also a low pressure drop across the sensor.





### **Type Overview**

Туре	DN	DN ["]	FS [l/s]	Δp [kPa]	PN	Voltage output
FM065F-SZ	65	2 1/2	9.6	12	16	0.510 V
FM080F-SZ	80	3	13.6	13	16	0.510 V
FM100F-SZ	100	4	24.0	12	16	0.510 V
FM125F-SZ	125	5	37.5	13	16	0.510 V
FM150F-SZ	150	6	54.0	15	16	0.510 V

FS: Full scale, maximum measurable flow

 $\Delta p$ : Pressure drop at FS

### **Technical Data**

Electrical data	Nominal voltage	AC/DC 24 V				
	Nominal voltage frequency	50/60 Hz				
	Nominal voltage range	AC 19.228.8 V / DC 21.628.8 V				
	Power consumption AC	1 VA				
	Power consumption DC	0.5 W				
	Connection supply	Cable , 3 x 0.75 mm <sup>2</sup>				
Functional data	Application	Water				
	Voltage output	0.510 V				
	Voltage output note	0 V = Missing power supply				
		0.3 V = Sensor error				
		0.5 V = 0% of FS				
		10 V = 100% of FS				
		max. load 1 mA				
	Pipe connection	Flange PN 16 according to EN 1092-2				
	Installation position	upright to horizontal				
	Servicing	maintenance-free				
Measuring data	Measuring values	Volumetric flow				
	Measuring fluid	Water and water glycol mixtures				
	Measuring principle	Ultrasonic volumetric flow measurement				
	Measuring accuracy flow	$\pm 2\%$ of the measured value (20100% FS) @ 20°C /				
		Glycol 0% vol.				
		±0.4% of FS (020% FS) @ 20°C / Glycol 0% vol.				
	Measuring accuracy flow note	±6% of the measured value (20100% FS)				
		±1.2% of FS (020% FS)				
	Flow Measurement Repeatability	±0.5%				
	Min. flow measurement	1% of FS				
Materials	Flow measuring pipe	EN-GJL-250 (GG 25), with protective paint				
Safety data	Ambient humidity	Max. 95% r.H., non-condensing				



Technical data sheet	FM
Ambient temperature	050°C [30120°F]
Fluid temperature	-20120°C [-5250°F]
Storage temperature	-4080°C
Protection class IEC/EN	III Safety Extra-Low Voltage (SELV)
Protection class UL	UL Class 2 Supply
Certification IEC/EN	IEC/EN 60730-1:11 and IEC/EN 60730-2-15:10
Degree of protection IEC/EN	IP54
Degree of protection NEMA/UL	NEMA 2
Enclosure	UL Enclosure Type 2
EMC	CE according to 2014/30/EU
Quality Standard	ISO 9001
Mode of operation	Туре 1
Control pollution degree	3
Rated impulse voltage supply	0.8 kV

Safety notes



This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application, especially in aircraft or in any other airborne means of transport.

Outdoor applications: Only possible where (sea) water, snow, ice, sunlight or aggressive gases cannot interfere directly with the device and it can be guaranteed that the ambient conditions remain at all times within the thresholds according to the data sheet.

Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied during installation.

The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.


**Product Features** 

Mode of operation	The ultrasonic flow sensor is equipped with a flow pipe, four flow transmitters and an electronic circuit temperature sensor is mounted in the flow pipe to compensate the temperature effects. A sensor error occurs when the ultrasonic path is interrupted (air bubbles in the system, connection to ultrasonic transducers interrupted).				
Patented glycol compensation	Glycol changes the viscosity of the heat transfer fluid and as a result affects the measured volumetric flow. Without glycol compensation, volumetric flow measurements can show errors of as much as 30 percent. The patented automatic glycol compensation significantly reduces the degree of measurement error.				

#### Installation notes

**Recommended installation positions** 

ns The sensor can be installed upright to horizontal. The sensor may not be installed in a hanging position.




Installation in return

Installation in the return is recommended.

Inlet section In order to achieve the specified measuring accuracy, a flow-calming section or inflow section in the direction of the flow is to be provided upstream from the flow sensor. Its dimensions should be at least 5x DN.



## Technical data sheet



Water quality requirements

nts The water quality requirements specified in VDI 2035 must be adhered to.

#### Servicing Ser


Sensors are maintenance-free.


Before any service work on the sensor is carried out, it is essential to isolate the sensor from the power supply (by unplugging the electrical cables if necessary). Any pumps in the part of the piping system concerned must also be switched off and the appropriate slide valves closed (allow all components to cool down first if necessary and always reduce the system pressure to ambient pressure level).

The system must not be returned to service until the sensor has been correctly reassembled in accordance with the instructions and the pipeline has been refilled by professionally trained personnel.


**Flow direction** The direction of flow, specified by an arrow on the housing, is to be complied with, since otherwise the flow rate will be measured incorrectly.

#### Wiring diagram





#### Dimensions



Туре	DN	DN ["]	L [mm]	H [mm]	D [mm]	d [mm]	K [mm]	X [mm]	Y [mm]	Weight
FM065F-SZ	65	2 1/2	240	193	185	4 x 19	145	263	132	13 kg
FM080F-SZ	80	3	260	200	200	8 x 19	160	270	140	15 kg
FM100F-SZ	100	4	262	202	230	8 x 19	180	272	155	18 kg
FM125F-SZ	125	5	314	209	255	8 x 19	210	279	167	24 kg
FM150F-SZ	150	6	334	219	285	8 x 23	240	289	182	30 kg